



# STANDARD OPERATING PROCEDURES **ECT1**

1. At the end of the workday always recharge to 100%.
2. If you can recharge between trips, please take advantage and do it.
3. If the vehicle is not to be driven for 48 hours or longer turn off the isolator switch. (see reverse).
4. Check tyre pressure once per week:  
550 kpa / 79 PSI.

## IMPORTANT DIMENSIONS

**HEIGHT: 2.715 m**

**WIDTH: 2.4 m**

**LENGTH: 6 m\***

(\*Allow an extra 1.5m to open the rear doors)

# STANDARD OPERATING PROCEDURES ECT1

## ISOLATION SWITCH OPERATION

1. Park the vehicle in a secure area
2. Lock vehicle
3. Locate the isolator switch on the passenger side chassis rail below the passenger side front door.



4. Turn the isolator switch clockwise so that the handle faces the front of the vehicle.

