# Volkswagen Tiguan & Tiguan Allspace Monochrome

EWK-660

# **Features and Specifications**

Safety and Security	Monochrome
Airbags	
Driver and front passenger airbags	S
Driver's knee airbag	S
Driver and front passenger side airbags	S
Curtain airbags, cover front and rear	S
Anti-theft	
Electronic engine immobiliser	S
Body	
Fully galvanised body with 12 year anti-corrosion perforation warranty	S
Door side impact protection	S
Rigid safety cell with front and rear crumple zones	S
Brakes	
Automatic flashing brake lights activated in emergency braking situation	S
Anti-lock Braking System (ABS)	S
Brake Assist	S
Electronic Brake-pressure Distribution (EBD)	S
Electro-mechanical parking brake	S
Auto hold function	S
Multi-collision brake	S
Child restraints	
Child seat top tether anchorage points, mounted on row 2 seat back (3)	S
ISOFIX child seat anchorage points, outer row 2 seats	S
_Head restraints	
Front safety optimised head restraints, longitudinal and height adjustable	S
Rear head restraints height adjustable	S
Locking	
Remote central locking	S
Keyless Access, keyless entry and starting system including starter button	S
2 stage unlocking (programmable)	S
Automatic locking after take-off (programmable)	S
One touch lock / unlock for driver	<u> </u>
Child safety locks on rear doors	S
Fuel filler flap lock/unlock by remote, push to open	S

### Safety and Security (continued)

#### Seat belts

Front height adjustable with pre-tensioners and belt force limiters	S
Outer row 2 seat belts with pre-tensioners and belt force limiters	S
Visual and acoustic warning for front and rear seat passenger seat belts not fastened	S
3 point seat belts for all passengers	S
3 point seat belts for all passengers	S

#### **Traction control**

Anti-Slip Regulation (ASR)	S
Electronic Differential Lock (EDL)	S
Electronic Stabilisation Program (ESP)	S
Extended Electronic Differential Lock (XDL)	S
4MOTION Active Control all-wheel drive with hill decent control	S

### **Exterior Equipment / Styling**

Monochrome

Body enhancements	
Black trim around window frames	S
Glossy black lower body side mouldings	S
Chrome radiator grille highlight top and bottom	S
Glossy black radiator grille highlights and centre	S
Lower air intake and rear bumper with glossy black highlight	S
Licence plate carrier in front with rear protective padding	S
Glossy black mirror caps	S
Design strip with R-Line logo on the front side panels	S
_Front bumper in R-Line design with gloss black C-signature air intakes	S
Lower body side extensions in body colour with black grain effect wheel arch extensions	S
Rear bumper with sports diffuser in gloss black	S
R-Line badge in radiator grille	S
R-Line rear spoiler in glossy black	S
Roof rails, black	S
Trapezoidal glossy black exhaust trims, left and right	S
Paint	
Metallic / Pearl Effect paint finish	S
Pearlescent paint finish	0
Tinted glass	
Dark tinted rear side window and rear window glass, 90% light absorbing	S

#### Heat insulating tinted glass

Wheels	
Alloy wheels, glossy black (Valencia) 19 x 8.5" with 255/45 R19 AirStop® tires	S
Anti-theft wheel bolts	S
Low tyre pressure indicator	S
Weight and space saving spare wheel	S

S

### **Comfort and Convenience**

#### Monochrome

Armrest	
Front centre armrest, adjustable with storage box and rear air outlets (2)	S
Row 2 centre armrest with cup holders (2)	S
Air conditioning	
Air conditioning, Air Care 3 zone automatic climate control with air cleaning function and allergen filter	
"Touch" climate controls front and rear	<u></u>
Dust and pollen filter	
Cup holders	
Front (2)	S
Row 2 (2) in centre armrest	S
Row 3 (1) (Tiguan Allspace only)	S
Bottle holders in front door pockets	S
Bottle holders in row 2 door pockets	S
Driver Assistance Technology Adaptive chassis control	S
Driving profile selection with 4MOTION Active Control	<u></u>
	3
Q.DRIVE*	
- Rear View Camera (RVC Plus) with multi-angle views and dynamic guidance lines - Travel Assist with Adaptive Lane Guidance	S
- Emergency Assist	S
- Adaptive Cruise Control with stop & go function	S
- Driver Fatigue Detection system	S
- Front Assist with Pedestrian Monitoring	S
- Lane Assist	S
- Manoeuvre braking, front and rear	S
- Park Assist, parking bay and parallel parking assistance	S
- Parking distance sensors, front and rear with acoustic warning and audio volume level reduction when sensor warning is activated	S
Floor mats	
Carpet floor mats and centre armrest with decorative stitching in Crystal Grey	
Grab handles	
Soft fold away grab handles, front and row 2	<u>\$</u>
Exterior Lighting	
Coming / leaving home function	S
Q.LIGHT LED Matrix headlamps with LED daytime drivings lights, dynamic cornering lights and dynamic turn signals	S
Dynamic Light Assist using Matrix LED technology	S
All-weather light function, illuminates the road in poor weather conditions	S
Ambient exterior lighting stip in front grill (Tiguan Allspace only)	S
ow light sensor with automatic headlight function	S
Rear fog lamp	<u></u> S
Rear registration plate light, LED	
	<u></u>
Rear tail lights, LED	S

\*Safety technologies are designed to assist the driver, but should not be used as a substitute for safe driving practices.

### **Comfort and Convenience (continued)**

Monochrome

S

S S

S

S S S

S

S

S S S S

In car entertainment and techn	
•	<u>llite navigation system</u> lay with smartphone style HMI and proximity sensor, Gesture Control, Voice Control, DAB+, AM & FM radio, 2D and 3D (bird's eye) map views, d service settings, security coded"
App-Connect USB-C interface for	or Apple CarPlay® and Android Auto™
Wireless App-Connect with App App-Connect featuring wireless Apple Ca	le CarPlay <sup>®</sup> and Android Auto™ rPlay <sup>®</sup> and wireless Android Auto™ is compatible with the latest versions of iOS and Android, active data service required, optional connection cable (sold separately).
Wireless phone charging (Tiguan	Allspace only)
Bluetooth <sup>®</sup> phone connectivity	with contacts display, operation via touch screen audio unit or Multi-Function Display and Bluetooth® audio streaming
Speakers, front and rear (8)	
USB-C ports (3), two Apple® con	npatible ports in front centre console, third charging port in rear
Instrumentation	
Digital Cockpit Pro, high resolut	ion 10.25" digital instrument colour display screen with customisable displays
Comfort indicator function (1 x	touch = 3 x flash)
Interior highlights	
Decorative inlays, "Carbon Grey"	to dashboard and door trims
Front door R-Line sill scuff plate	s in aluminium finish, illuminated
Black headlining and pillar trim	
Gearshift knob with leather and	matte chrome finish
Interior lighting	

S
S
S

Luggage	compartment

_Manually operated tailgate	S
Load restraining hooks	S
Luggage compartment floor adjustable in 2 heights	S
Luggage compartment light is also a removable torch (Tiguan Allspace only)	S
Shopping bag hook	S
12 volt socket	S

Mirrors	
Automatic dimming interior rear-view mirror	S
Electrically foldable exterior mirrors with environment lighting and automatic kerb function when reversing, passenger's side	S
Electrically heated and adjustable exterior mirrors	S
Exterior mirrors with integrated LED turn indicators	S
Power steering	
Electro-mechanical, vehicle speed and steering input sensitive	S
Progressive steering	S

Progressive steering

### Comfort and Convenience (continued)

#### Monochrome

Seating	
Comfort sport front seats	S
Manual adjustment for front seats including height adjustment	S
Lumbar adjustment for front seats, manually adjustable	S
Split folding row 2 seats (40/20/40)	S
Row 2 seat backrest with angle adjustment and longitudinally sliding seat base	S
Row 2 seat backrest remote release	S
Row 2 seat centre armrest with cup holders (2)	S
Row 3 with two split stowable seats (Tiguan Allspace only)	S
Steering wheel	
3 spoke R-Line leather covered flat bottomed steering wheel with "Touch" controls	S
Audio, telephone, IQ.DRIVE and Digital Cockpit Pro controls	S
Gearshift paddles	S
Height and reach adjustable steering wheel	S
Storage	
Centre console storage compartment under armrest	S
Centre dashboard top compartment with lid	<u></u>
Glove compartment with cooling and illumination	<u></u> S
Tray and 12 volt socket in console	<u></u> S
Drawers under front seats	<u></u>
Driver's side dashboard compartment with lid	<u></u>
Front door compartments with bottle holders	S
Front seat backrest storage pockets	
Net on front passenger's side of centre console	S
Overhead roof console with storage compartments (Not fitted in combination with the optional Panoramic glass sunroof)	S
Row 2 door compartments with bottle holders	S
Sunroof	
Panoramic glass sunroof	
Electrically slide and tilt adjustable front half section	0
Integrated wind deflector and electrically operated (perforated) sunblind	0
Please note: The overhead storage compartments are not fitted in combination with this option	
Transmission	
7 speed Direct Shift Gearbox (DSG) with sport mode and Tiptronic function	\$
Upholstery	
ArtVelor/cloth R-Line seat upholstery with R-Line logo and decorative stitching in Crystal Grey	S
Vanity mirrors	
Driver's and passenger's side vanity mirrors in sun visor with ticket holder	S
Illuminated on driver's and passenger's side	S

### Comfort and Convenience (continued)

#### Monochrome

Wipers	
2 speed aero wipers with wash/wipe	S
Rain sensor	S
Rear window with wash/wipe and intermittent wipe	S
Warning light for low washer fluid level	S
Windows	
Power front /rear, with roll-back function and one-touch up-down	S
Remote operated convenience close and open feature (programmable)	S
12V socket	
Centre console, front and rear	S
Luggage compartment	S S



# **Technical Specifications**

Model	Tiguan 162TSI Monochrome	Tiguan Allspace 162TSI Monochrome	
Engine	2.0 litre TSI	2.0 litre TSI	
Туре	4 cylinder inline turbocharged direct injection petrol with engine Start/Stop system*	4 cylinder inline turbocharged direct injection petrol with engine Start/Stop system*	
Installation	Front transverse	Front transverse	
Cubic capacity, litres/cc	2.0/1984	2.0/1984	
Bore/stoke, mm	82.5/92.8	82.5/92.8	
Max power, kW @ rpm	162 @ 4200-6000	162 @ 4300-6200	
Max torque, Nm @ rpm	350 @ 1500-4000	350 @ 1600-4200	
Fuel type (Recommended) Premium unleaded 95 RON minimum		Premium unleaded 95 RON minimum	
Transmission	7 Speed DSG	7 Speed DSG	
Driven wheels	4MOTION all-wheel drive	4MOTION all-wheel drive	
Fuel Consumption~			
Combined, L/100km	8.5	8.6	
Urban, L/100km Extra Urban, L/100km	10.4 7.4	10.7 7.5	
CO2 emission g/km	195	197	
Fuel tank capacity litres	60 60		

\*The Start/Stop system is designed to reduce fuel consumption and CO2 emissions. It achieves this by automatically switching off the engine while the vehicle is stationary and then starting it again automatically when the driver wants to drive off. There are certain operating conditions where the Start/Stop system is deactivated (e.g. during engine warm-up), please refer to the owner's manual for full operating information.

~ Fuel consumption figures accordign to ADR 81/02 derived from laboratory testing. Factors including but not limited to driving style, road and traffic conditions, environmental influences, vehicle condition and accessories fitted,

will in practice in the real world lead to figures which generally differ from those advertised. Advertised figures are meant for comparison amongst vehicles only.

# Please note figures are sourced from overseas data where equipment levels by model variant may vary.

x Please note running clearance measurement may vary with wheel size, tyre pressures, tread depth.

+ With rear seat in the forward position

# **Technical Specifications**

	Tiguan 162TSI Monochrome	Tiguan Allspace 162TSI Monochrome	
Running gear Suspension			
Front axle	Independent, MacPherson strut	s with lower A-arms. Anti-roll bar.	
Rear axle	Independent, four-link wi	th coil springs. Anti-roll bar.	
teering	Electro-mechanical power a	issisted rack & pinion steering.	
Brake Systems	Anti-lock Braking System (ABS) with Electronic Brake-pressure Dist	ribution (EBD), Brake Assist and Electronic Stabilisation Program (ESP)	
Brakes			
Front	Ventilated Discs	Ventilated Discs	
Rear	Discs	Discs	
urning Circle (m)	11.9	11.9	
Veights			
are Mass kg's	1699	1796	
owing Capacity	Please refer to the specific Vehicle Towing page.	Please refer to the specific Vehicle Towing page.	
exterior Dimensions			
)verall length mm	4509	4734	
/idth mm	1839	1839	
leight mm	1686	1688	
Vheelbase mm	2681	2791	
rack mm			
Front	1586	1585	
Rear	1576	1575	
Running clearance mm¤	185	186	

\*The Start/Stop system is designed to reduce fuel consumption and CO2 emissions. It achieves this by automatically switching off the engine while the vehicle is stationary and then starting it again automatically when the driver wants to drive off. There are certain operating conditions where the Start/Stop system is deactivated (e.g. during engine warm-up), please refer to the owner's manual for full operating information.

~ Fuel consumption figures accordign to ADR 81/02 derived from laboratory testing. Factors including but not limited to driving style, road and traffic conditions, environmental influences, vehicle condition and accessories fitted,

will in practice in the real world lead to figures which generally differ from those advertised. Advertised figures are meant for comparison amongst vehicles only.

# Please note figures are sourced from overseas data where equipment levels by model variant may vary.

x Please note running clearance measurement may vary with wheel size, tyre pressures, tread depth.

+ With rear seat in the forward position

## **Technical Specifications**

	Tiguan 162TSI Monochrome	Tiguan Allspace 162TSI Monochrome
Luggage Area Dimensions#		
Luggage area volume L		
Row 2 folded	1655	
Row 2 upright <sup>+</sup>	615	
Row 3 & 2 folded		1775
Row 3 folded with row 2 upright <sup>+</sup>		700
Row 3 upright		230
Luggage area floor length mm		
Row 2 seat upright <sup>+</sup>	977	1046
Row 2 seat folded	1746	1921

\*The Start/Stop system is designed to reduce fuel consumption and CO2 emissions. It achieves this by automatically switching off the engine while the vehicle is stationary and then starting it again automatically when the driver wants to drive off. There are certain operating conditions where the Start/Stop system is deactivated (e.g. during engine warm-up), please refer to the owner's manual for full operating information.

~ Fuel consumption figures accordign to ADR 81/02 derived from laboratory testing. Factors including but not limited to driving style, road and traffic conditions, environmental influences, vehicle condition and accessories fitted,

will in practice in the real world lead to figures which generally differ from those advertised. Advertised figures are meant for comparison amongst vehicles only.

# Please note figures are sourced from overseas data where equipment levels by model variant may vary.

¤ Please note running clearance measurement may vary with wheel size, tyre pressures, tread depth.

+ With rear seat in the forward position

## **Colour Combinations**

Interior Trim	Exterior Colours					
	Reflex Silver M	Pyrite Silver M	Dolphin Grey M	Platinum Grey M	Deep Black PE	Oryx White PL
Tiguan Monochrome						
ArtVelor/cloth seat upholstery for R-Line with R-Line logo	S		S		S	S
Tiguan Allspace Monochrome						
ArtVelor/cloth seat upholstery for R-Line with R-Line logo		S		S	S	S

Please note: Metallic (M) and Pearl Effect (PE) paint are included in the vehicle cost. Pearlescent (PL) paint is optional at an additional cost

# Vehicle Towing

The Owner's Manual contains both general and detailed specific information relating to the vehicle's ability for the towing of trailers and should be referenced to ensure familiarity with its contents. In addition to this information it should also be noted that for the Australian market the maximum permitted vertical load exerted by the trailer drawbar on the ball head of the towing bracket must not exceed the values as stated and shown for each model type below.

Different trailer types and different trailer manufacturers have varying towball downloads. The customer should always contact the trailer manufacturer for information as to the maximum download weight. Volkswagen does not recommend the fitting of load levelling or weight distribution devices when used with a Volkswagen Genuine towbar. When fitted and used correctly, the Volkswagen Genuine towbar is capable of meeting the towbar/towball capacities as stated and shown for each model type below.

#### **Towing Capacity**

NOTE: Towbar capacities n Volkswagen Group Austral	nust not be exceeded. Volkswagen Group ia does not endorse or will not be held lial	Australia recommends the use of a Genuine Volkswagen Act ole for any claim, loss or damage arising from the use or fit	cessory Towbar. ment of electronic trailer brakes.
Tiguan Variant	Model Code	Towbar Capacity Unbraked	Towbar Capacity Braked
162TSI Monochrome	AX**WT	750 kg	2500 kg
Tiguan Allspace Variant			
162TSI Monochrome	BJ**TT	750 kg	2500 kg

Maximum Permitted Gross Rear Axle Weight Rating and Maximum Downball Weight

NOTE: The Maximum Perm The Maximum Downball W	itted Gross Rear Axle Weight Rating leight must also not be exceeded	is inclusive of the Maximum Downball Weight and must not be exce	eeded.
Tiguan Variant	Model Code	Maximum Permitted Gross Rear Axle Weight Rating	Maximum Downball Weight
162TSI Monochrome	AX**WT	1,150 kg	200 kg
Tiguan Allspace Variant			
162TSI Monochrome	BJ**TT	1330 kg	200 kg

#### Maximum Gross Vehicle Mass and Maximum Gross Combination Mass

NOTE: The Maximum Gross Vehicle Mass (GVM) and Maximum Gross Combination Mass (GCM) must not be exceeded.				
Tiguan Variant	Model Code	Maximum Permitted Gross Rear Axle Weight Rating	Maximum Gross Combination Mass (GCM)	
162TSI Monochrome	AX**WT	2,260 kg	4,760 kg	
Tiguan Allspace Variant				
162TSI Monochrome	BJ**TT	2440 kg	4940 kg	

Please note towbar capacities are applicable to the Genuine Volkswagen Accessory towbar.

Volkswagen Group Australia does not endorse or will not be held liable for any claim, loss or damage arising from the use or fitment of electronic trailer brakes. Data is for model year 2023 vehicles.

# Glossary

### Adaptive Cruise Control (ACC)

Adaptive Cruise Control (ACC) is an extension of the conventional cruise control system with advanced capabilities based on a radar sensor. When ACC is activated, the vehicle automatically brakes and accelerates to a speed and distance set by the driver.

If the Tiguan approaches a slower vehicle, the ACC brakes the car to the same speed and maintains the pre-selected distance. Even when a vehicle pulls into the same lane in front of you or slows, your vehicle is automatically decelerated to the pre-selected distance. If the vehicle ahead moves out of your lane, the Tiguan then accelerates up to the pre-set desired speed.

Deceleration of the vehicle may take place via intervention in the engine management system. If deceleration via engine torque is not sufficient, brake intervention takes place, braking the vehicle to a standstill if the traffic situation necessitates. ACC can be reactivated automatically by depressing the accelerator pedal.

The dynamics of the ACC system can by individually varied by selecting one of the driving programs from the driver profile selector.

Adaptive Cruise Control (ACC) cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain.

#### Anti-lock Braking System (ABS)

When braking, wheel speed sensors measure the road wheel speed and should one or more wheels start to lock the ABS system reduces brake pressure to that wheel. This prevents the wheels from locking during heavy or emergency braking, enabling the vehicle to remain steerable.

#### Anti-Slip Regulation (ASR)

ASR is a traction control system that prevents the wheels from spinning under acceleration by reducing engine torque.

#### **Auto Hold function**

As soon as the vehicle comes to a complete stop, the ABS hydraulic unit stores the vehicles final braking pressure. So even when you take your foot off the brake pedal, all four wheels brakes remain applied, providing increased comfort in stationary traffic. This function is released automatically when you drive off again.

#### **Brake Assist**

During emergency braking, Brake Assist aids the driver by increasing the brake pressure automatically to a level exceeding the locking limit. The ABS is thus quickly brought into the operating range, which enables maximum vehicle deceleration to be achieved.

### **Emergency Assist**

Emergency Assist monitors the driving characteristics and recognises, within the limits of the system, if the driver suddenly becomes incapable of driving (due to the vehicle not being controlled).

Emergency Assist detects a lack of activity on the part of the driver and issues repeated visual and acoustic warnings and initiates a quick jolt of the brakes to request the driver to take control of the vehicle.

If the driver remains inactive, the system automatically controls acceleration, braking and steering to slow the vehicle down and keep it in the lane. If there is sufficient stopping distance, the system decelerates the vehicle to a complete stop and switches on the electronic parking brake automatically.

When Emergency Assist is actively controlling the vehicle, the hazard warning lights are switched on and the vehicle performs a slight snaking motion within its lane to warn other road users. Ideally this will prevent a collision, or at least reduce its severity.

Emergency Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Emergency Assist utilises both the Adaptive Cruise Control (ACC) and Lane Assist driver assistance systems. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

#### **Electronic Brake-pressure Distribution (EBD)**

Electronic, more sophisticated means of regulating the ratio of front/rear brake pressure. Settings are varied according to driving and load conditions to ensure each wheel is braked to the optimum extent.

### **Electronic Stabilisation Program (ESP)**

ABS and ASR traction control systems are integrated into the Electronic Stabilisation Program (ESP). In short, ESP helps ensure that the vehicle goes where you steer it even in extreme driving conditions. The ESP system constantly compares the actual movement of the vehicle with pre-determined values and should a situation arise where the vehicle starts to skid, ESP will apply the brakes to individual wheels and automatically adjust the engine's power output to correct the problem. ESP prevents the vehicle from losing control when trying to avoid an accident, for example. It also reduces the effects of understeer or oversteer.

### **Extended Electronic Differential Lock (XDL)**

XDL is an extension of the Electronic Differential Lock (EDL) function. When cornering, XDL responds to the load relief at the driven wheel/s on the inside of a corner. The ESP hydraulics are used for the XDL to apply pressure to the wheel on the inside of the corner in order to prevent wheel spin. This improves traction and reduces the tendency to understeer. As a direct result of the one-sided and precise braking pressure, cornering is sportier and more accurate.

# Glossary

#### **Fatigue Detection**

The driver Fatigue Detection system automatically analyses the driving characteristics and if they indicate possible fatigue, recommends that the driver takes a break. The system continually evaluates steering wheel movements along with other signals in the vehicle on motorways and others roads at speeds in excess of 60 km/h, and calculates a fatigue estimate. If fatigue is detected, the driver is warned by information in the Digital Cockpit Pro and an acoustic signal. The warning is repeated after 15 minutes if the driver has not taken a break.

Fatigue Detection cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and therefore determining whether or not they are fit to drive. A driving time of 15 minutes is required in order to assess the driver correctly. The functionality of the system is restricted given a sporty driving style, winding roads and poor road surfaces.

### Front Assist with Pedestrian Monitoring

The Front Assist is both a high and low speed AEB monitoring system which uses a radar sensor to detect critical distance situations and thus help to shorten the braking distance, reducing the risk of a rear-end collision.

The traffic ahead is monitored constantly by the radar at the front. If a vehicle is detected ahead of you in the lane, the distance and the speed relative to it are calculated. If the gap is closing too fast, Front Assist initially warns the driver by means of an audible as well as a visual signal. At the same time, the brake pads are brought into contact with the brake discs and the sensitivity of the Brake Assist is increased. This primes the braking system for a possible emergency stop. Furthermore, an automatic jolt of the brakes warns the driver of the danger. If the driver also fails to react to the warning jolt, Front Assist brakes automatically, helping to avoid a collision or reduce the severity of the accident.

At vehicle speeds below 30km/h, Front Assist monitors the area ahead of the car for vehicles which might present a threat of collision. If a collision is likely, Front Assist first pre-charges the brakes and makes the emergency Brake Assist system more sensitive: if the driver should notice the risk, the car is ready to respond more quickly to their braking action. However, if the driver still takes no action and a collision becomes imminent, City Emergency Braking independently applies the brakes very hard. If the driver intervenes to try to avoid the accident, either by accelerating hard or by steering, Front Assist will deactivate and allow the driver to complete the avoidance manoeuvre.

Pedestrian Monitoring is an extension of the Front Assist monitoring system. The system uses a camera to monitor the side of the road and a radar sensor in the radiator grille to monitor the area in front of the vehicle and within the limits of the system, register certain situations, for example a pedestrian stepping onto the road suddenly. Using the camera the system detects pedestrians on the side of the road and gives an immediate acoustic and visual signal to warn the driver of the possibility of danger. If the radar sensor than detects the pedestrian and the driver does not brake, the system initiates a jolt of the brake as a warning about the critical situation, while at the same time preparing for hard braking. If the driver fails to react, the system automatically performs emergency braking, within system limits. Ideally this will prevent a collision, or at least reduce its severity.

Front Assist with Pedestrian Monitoring cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles.

#### Lane Assist

Lane Assist is a lane departure warning system that is designed to help reduce the likelihood of the vehicle leaving the road or crossing into on oncoming lane and therefore the risk of accident as a result of driver distraction or a lapse in concentration.

The Lane Assist system monitors the road ahead with the aid of a camera (located near the interior rear-view mirror) which recognises lane markings and evaluates the position of the vehicle. If the vehicle starts to leave the lane, the Lane Assist system takes corrective steering action. If this is not sufficient the driver is warned about the situation by a steering vibration and is asked to take over the steering. Additionally, if no active steering movements by the driver are recognised for longer than approximately 8 seconds, a message will appear in the Digital Cockpit Pro in conjunction with a warning tone. The corrective steering function can be overridden by the driver at any time and the system does not react if the turn indicator is set before crossing a lane marking.

When **adaptive lane guidance** is active when using Travel Assist and the system detects both lane markings to the left and right of the vehicle, the function provides permanent assistance while the vehicle is in motion.

Lane Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and therefore staying in the lane at all times. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system. The Lane Assist system does not activate at a vehicle speed of less than 65km/h.

#### Manoeuvre braking

Manoeuvre braking assists the driver to avoid or reduce damage in a potential collision by initiating emergency braking. It supports the driver during forward and reverse manoeuvring in a speed range of a maximum 10 km/h. If the risk for an accident is recognised, emergency braking is initiated to minimise possible damage.

Manoeuvre braking cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle. The object must be detected by the sensors. If the driver notices a risk that pedestrians, other vehicles or objects could be damaged they need to react accordingly and stop the vehicle.

#### **Multi-collision brake**

The multi-collision brake has been designed to provide effective assistance for the driver in the moments after an accident. Multi-collision brake triggers automatic controlled braking once an initial collision has been detected so as to reduce the intensity of further accidents after a collision and can help prevent follow-on collisions with oncoming traffic.

The triggering of the multi-collision brake is based on a collision being detected by the airbag sensors. The ESP control unit limits the deceleration of the vehicle by the multi-collision brake to a defined value and vehicle speed. The vehicle can still be controlled by the driver, even when automatic braking is taking place. The driver can interrupt the multi-collision braking at any time by accelerating or braking even more strongly.

# Glossary

#### **Park Assist**

The third generation Park Assist system actively helps the driver when entering or reversing into 90° parking bays, as well as reversing into and driving out of parallel parking spaces. The system works by using sensors mounted either side of the front and rear bumpers together with parking distance sensors front and rear. To park, the driver simply presses the Park Assist button to select the type of parking manoeuvre and uses the appropriate indicator as the car slowly passes the potential parking space. Sensors scan the size of the parking space as the car is driven past and the driver is alerted if the parking space is big enough. If there is sufficient space, the driver stops the car, selects the correct gear and lets go of the steering wheel.

Park Assist will alert the driver of the intended path and subsequently the appearance of obstacles in the Digital Cockpit Pro, within the driver's field of vision. Park Assist then actively supports the driver by taking over the steering control and parks the vehicle in the available space using the ideal course, if necessary with several moves. The driver can however take over the control of the steering at any time and end the automatic parking procedure.

Park Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle. If the driver notices a risk that pedestrians, other vehicles or objects could be damaged or if they are uncertain of the risk, they will need to react accordingly and stop the vehicle, ending the function.

#### **Travel Assist**

Travel Assist is an assistance system for partly automated driving. At the push of a button, Travel Assist can support the driver in monotonous and tiring driving situations commonly encountered on long motorway journeys. This system combines the functions of Adaptive Cruise Control (ACC), Lane Assist with adaptive lane guidance to accelerate, brake and maintain the vehicles position within its lane. The capacitive steering wheel can detect whether the driver's hands are on the steering wheel in readiness to steer the vehicle and will issue a visual and audible warning when not detected.

Travel Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Travel Assist has been developed for use only on motorways. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.



# Volkswagen Tiguan & Tiguan Allspace Monochrome

Volkswagen Group Australia Pty Ltd 895 South Dowling Street, Zetland NSW 2017 ABN 14 093 117 876

Produced in Australia December 2022

Publication: VWPTIGASMPMY22

Important Information

Volkswagen is distributed by Volkswagen Group Australia Pty Ltd, 24 Muir Road Chullora, NSW 2190. ABN 14 093 117 876. Specifications are as planned at July 2022, for Model Year 2023 and are subject to change without notice or obligation. All information is this specification sheet is correct at the time of publication, however variations may occur from time to time and Volkswagen, in so far as it is permitted by law to do so, shall not be liable in any way as a result of any reliance by any person on anything contained in this specification sheet. Authorised Volkswagen dealers will provide up-to-date information on model application, design feature, prices and availability on request.

Apple CarPlay<sup>®</sup> and Apple Lightning<sup>®</sup> are registered trademarks of Apple Inc. Android Auto<sup>™</sup> is a registered trademark of Google Inc. MirrorLink<sup>®</sup> is a registered trademark of Car Connectivity Consortium LLC. Bluetooth<sup>®</sup> is a registered trademark of Bluetooth SIG Inc.