



## SERVICE SCHEDULE



### IMT GREASE LUBRICATED AXLE TYPES F22, FE22, FE24

SERVICE SCHEDULE		After first 5000kms	Periodic checks		
Mileage intervals	Which ever comes first >			Every 30,000km	Every 120,000km
Time intervals		After first month	Every Month	Every 3 months	Every 12 months

INSPECTIONS				
Remove hub cap and inspect grease around outer bearing and in hub cap for contamination				●
Clean and repack bearings and hub with fresh grease				●
Check condition of taper roller bearings, Replace if necessary				●

\*original equipment uses VERTEX Never Melt grease

GENERAL for wear / damage				
Check wheel bearings for excessive play, adjust as required (Min 0.25, Max 0.16mm)	●	●		
Check hubs for correct rotation, loss of lubricant and free of bearing noise	●	●		
Check brake linings for wear	●	●		
Check brakes for correct adjustment	●	●		
Check braking system for air leaks	●	●	●	
Check truck-trailer combination for brake compatibility	●			●
Check calipers for free movement	●	●		

**Special service conditions;**

**Vehicles operating in off highway / harsh conditions; service at suitably reduced time intervals to suit the vehicle operation**